

Crane Scale User Manual



Soluciones de pesaje y
equipos para alimentos



Model:OCS-SF


Manual usuario BBG ref SF



7

TABLE OF CONTENTS

SAFE OPERATION GUIDE -----	2
CHAPTER 1 FEATURES AND SPECIFICATION -----	3
1 Features-----	3
2 Main technical data-----	3
3 Dimension and specification-----	4
4 Power supply-----	5
CHAPTER 2 DISPLAY -----	5
1 Led display-----	5
2 Indicator lamp-----	5
3 Key-----	5
4 Remote control-----	6
CHAPTER 3 OPERATION GUIDE -----	7
1 Turn on/off-----	7
2 Zero-----	7
3 Tare-----	7
4 Hold-----	7
5 Peak-----	7
6 Accumulation-----	8
7 Accumulation Search-----	8
8 Accumulation Clear-----	8
9 Battery Voltage-----	8
10 Brightness-----	8
11 Zero Point-----	8
12 Unit-----	8
CHAPTER 4 SIGNAL ILLUSTRATION -----	9
CHAPTER 5 TROUBLESHOOTING GUIDE -----	10



SAFE OPERATION GUIDE:

1. The capacity of crane scale have been showed on the overlay, Don't make lifts beyond rated capacity of the crane scale.
2. Operators should not maneuver a loaded crane scale over-personnel.
3. The scale must be routinely checked for operation. Don't operate if hook, shackle, sling, cable, etc show any sign of defects or excessive wear.
4. If the scale is not going to be used for long time, recharging the battery every three months to preserve the life-span of the battery and recharge it before operation.
5. The battery charger is included in the scale package. Please use this charger. It's normal that the charger will become warm when the battery is charging.
6. Please note when the digits flash on the display, it means that the battery needs to be recharged.
7. Check hook, shackle, safety pins, and latches periodically. Contact your dealer for parts replacement in case defect, deform or wearing is found.
8. Always lift loads vertically.

CHAPTER 1 FEATURES AND SPECIFICATION


1. Features

- ◆ **Rotating hook:** 360° safe rotated hook, convenient to use
- ◆ **Multi-weighing units:**
Kg, lb, N are selectable, generally kg are default unit.
- ◆ **Multi-function operation:**
Tare, Zero, Auto zero tracking, Total, Hold, Overload warning and record, Calibration through remote controller, etc functions.
- ◆ **User-friendly design:**
Die casting plastic housing for maximum protection; Large red 5 digit LED display (digit height 20mm); Gravity compensation; Safety factor up to 4 times capacity; Battery Operated with low battery indication; Automatic turn off , power-saving function.

2. Main technical data

Standard	According to OIML class III
Display	20mm (0.8") 5digits LCD/LED
Zero Range	4% F.S.
Tare Range	100% F.S.
Stable Time	≤10 seconds
Overload Indication	100% F.S. + 9e
Max. Safety Load	125% F.S.
Ultimate Load	400% F.S.
Battery Life	≥70 hours
Battery Type	Fully sealed Lead-Acid battery, 4V/2Ah Or AA size battery, 1.5V × 3, user selectable
Adapter	DC6V/500mA Lead-Acid adapter
Nominal operating Temp.	- 10℃ ~ + 40℃
Operating Humidity	≤85% RH under 20℃
Remote Controller Distance	Min. 15m
Battery of Remote Controller	AAA Size battery, 1.5V × 2

3. Dimension and specification



Dimensions and Specifications:


MODEL	Cap.(kg)	Resolution(kg)	NW(kg)	GW(kg)
OCS-SF-003	30	0.01	0.95	1.2
OCS-SF-005	50	0.02	0.95	1.2
OCS-SF-01	100	0.05	0.95	1.2
OCS-SF-015	150	0.05	0.95	1.2
OCS-SF-02	200	0.1	0.95	1.2
OCS-SF-03	300	0.1	0.95	1.2

4. Power supply

Battery: 4V/2Ah fully sealed Lead-Acid battery or 3pcs 1.5V AA size Batteries
 Adapter: 6V/500mA special Lead-Acid adapter

Current: the crane scale average current is about DC 20mA±10%, if battery charged, it can be used for about 70hours.Low battery warning: When the digits flash, it means the battery needs to be recharged. The scale will power off automatically after 1 to 2 hours operation if the battery is not charged. Please recharge the battery before operating the scale again.
 Charging method: Turn off the crane scale, use adapter in the carton, the lamp on the adapter will become green when charging, and it will become red when the charging finish.
 Generally, charging time should not less than 8hours, the crane scale have charging protection, long time charging can't damage the battery.

CHAPTER 2 DISPLAY



1. LED DISPLAY

20mm (0.8") 5digits LED/LCD

2. INDICATOR LAMP

- a. ZERO: ZERO indicator
- b. TARE: TARE indicator
- c. HOLD: HOLD indicator
- d. STB: STABLE indicator
- e. lb : lb unit indicator
- f. kg : kg unit indicator
- g. N : Newton unit indicator

3. KEY

- a. : ON/OFF

1. Press three seconds. the crane scale turn on.
2. When turn on: Press three seconds. the crane scale turn off.

- b. : ZERO


When crane scale switch on with no load on the hook, but there are small digits on screen, press this key to obtain zero reading. The "ZERO" indicator switches on.

- c. : TARE

1. Hang sling or container on the hook, when the weight reading stable, press this key, the digits display "0", and "TARE" indicator switch on.
2. Put the goods into container, the scale will display goods net weight.
3. If move goods and container, the scale will display minus value of tare weight.

- d. : HOLD

1. When weight is changing, press this key will hold the reading, and "HOLD" indicator switch on.
2. Press this key again, reading will resume changing, and "HOLD" indicator switch off.



4. REMOTE CONTROLLER



Press any key on the remote controller, the indicator on the controller will flash.

Key function:

1. **【ZERO】**
 - a. In weighing status, when crane scale switch on with no load on the hook, but there are small digits on screen, press this key to obtain zero reading.
 - b. In parameter setting and calibration process, it used for set value up
2. **【TARE】**
 - a. In weighing status, the function is equal to TARE on front panel
 - b. In parameter setting and calibration process, it used for move digit (the digit choose flash)
3. **【SHIFT】**
 - a. In weighing situation, used for function shift, or used with other key to more function.
 - b. In parameter setting and calibration process, it used for confirm setting.
4. **【CLEAR】**
 - a. In weighing status, it used to clear accumulation.
 - b. In parameter setting and calibration process, it used for set value down.
5. **【ACCU】**
It used for accumulation function, details see Chapter3-5.
6. **【F1】**
Function Key. used with **【F2】** together, Press **【F1】** solely, it will regulate brightness of LED.
7. **【F2】**
Function Key. used with **【F1】** together.
8. **【HOLD】**
It used for hold function, details see Chapter3-4.
9. **【PEAK】**
It used for hold function, details see Chapter3-5.
10. **【OFF】**
Turn off the crane scale

CHAPTER 3 OPERATION GUIDE

【】 express key on remote controller.

1 TURN ON/OFF

◆TURN ON

Press **⏻** one seconds, the screen display as follows:

OPERATION	DISPLAY	ILLUSTRATION
Press ⏻	[[88888]]	Display two times
	[[u=1.05]]	Display two times, ERT is Everight abbreviation
	[[XXXXX]]	Display capacity
	[[U4.XX]]	Display current battery voltage
	[[----]]	Waiting stable
	[[0.00]]	"STB" light on, you can operate now

◆TURN OFF

1	Press ⏻ one seconds.
2	Press 【OFF】 three seconds.
3	Choose turn off method when parameter setting, the scale will display [[-]] after no operation at 15minutes to save power, and it will turn off automatically after 60minutes.

2 ZERO

OPERATION	DISPLAY	ILLUSTRATION
Press 【ZERO】	[[0]]	When scale turn on, generally scale displays [[0]] , if display small digits when no load, press this key.

3 TARE

◆TARE DIRECTLY

OPERATION	DISPLAY	ILLUSTRATION
1 Press ⏻	[[0]]	After turn on, hanging tare weight such as sling, cable at first, press this key, "TARE" light on, then the scale will display net weight of the goods.
2 Press 【TARE】	[[0]]	

4 HOLD

OPERATION	ILLUSTRATION
Press 【HOLD】	Hold the weight reading no matter load change
Press 【HOLD】 again	Return to normal weighing status

5 PEAK

OPERATION	ILLUSTRATION
Press 【PEAK】	Before weighing, press this key, the HOLD lamp will flash and the scale will get the peak value of the load.
Press 【PEAK】 again	The HOLD lamp will not flash again and the scale return to normal weighing status

6 ACCUMULATION

OPERATION	DISPLAY	ILLUSTRATION
Press 【ACCU】	[[No***]]	Current accumulation time
	[[H****]]	Front four digits of total value
	[[L****]]	Rear four digits of total value

After display above contents two times, the scale will return automatically, you also can press **【SHIFT】** to return.

7 ACCUMULATION SEARCH

OPERATION	DISPLAY	ILLUSTRATION
【SHIFT】【ACCU】	[[No.***]]	Current accumulation time
	[[****]]	Current weight reading
	[[H****]]	Front four digits of total value
	[[L****]]	Rear four digits of total value
【SHIFT】	[[****]]	Return

Press **【TARE】** and **【ZERO】** can check different times weight and accumulation.

8 ACCUMULATION CLEAR

OPERATION	DISPLAY	ILLUSTRATION
【CLEAR】	[[CLr]]	Ask if you want to clear or not
【CLEAR】	[[noCLr]]	Cancel clear
【SHIFT】	[[8.8.8.8.8.]]	Confirm clear

9 BATTERY VOLTAGE

OPERATION	DISPLAY	ILLUSTRATION
【SHIFT】【F1】	[[U 4.**]]	Display current battery voltage
【SHIFT】		Return

The voltage should be between 3.8 and 4.6, if below than 3.8, the digits flash, you need to recharge immediately.

10 BRIGHTNESS

OPERATION	ILLUSTRATION
【F1】	1-8 total 8 options, from darkness to brightness(Default is 5)

11 ZERO POINT

OPERATION	ILLUSTRATION
【SHIFT】【ZERO】	Display current zero point

12 UNIT

OPERATION	ILLUSTRATION
【SHIFT】【HOLD】	Unit switch, Un=0: kg, "kg" light on, Un=1: lb, "lb" light on. Un=2: Newton, "N" light on.

CHAPTER 4 DISPLAY ILLUSTRATION

DISPLAY	ILLUSTRATION	REMARK
[[CALSP]]	Enter zero point calibration	
[[SCALE]]	Enter calibration	
[[SEIUP]]	Enter parameter setting	
[[UAd]]	Enter voltage calibration	
[[LoAd1]]	First calibration point	LoAd1<LoAd2<LoAd3
[[LoAd2]]	Second calibration point	
[[LoAd3]]	Third calibration point	
[[]]	Exceed high limit	Tare weight can't exceed full capacity
[[]]	Exceed low limit	Tare weight can't be negative
[[----]]	Waiting	
[[Err10]]	Weight less than Min. Capacity	Can't accumulate the value
[[Err11]]	Accumulated times overflow	Can't accumulate after 30times
[[Err12]]	Accumulated weight overflow	Can't accumulate after 99999
[[Err13]]	Error in repeat accumulation	Can't accumulate one weight repeatedly
[[no***]]	Current accumulation times	
[[H****]]	Front four digit of accumulated weight	Total weight=front four digit + rare four digit
[[L****]]	Rare four digit of accumulated weight	Total weight=front four digit + rare four digit
[[CLr]]	Ask if you really want to delete accumulated weight	In case error deletion
[[noCLr]]	Give up deletion	
[[8888]]	Confirm deletion	
[[SHIFT]]	Switch	
[[]]	Input value is too large	When you input tare or weight value
[[]]	Input value is too small	When you input tare or weight value
[[noACC]]	No any accumulated content	when you check accumulation
[[oL-]]	Overload warning	Tare + Net weight exceed full capacity + 9e
[[Lb-]]	Low battery warning	Turn off automatically one minute later
[[U.**]]	The voltage of current battery	
[[End]]	End	when parameter setting or calibration ready
[[OFF]]	Turn off	
[[Unstb]]	Input value before STB light on	

CHAPTER 5 TROUBLESHOOTING GUIDE

PROBLEM	POSSIBLE CAUSE	SOLUTION
No display when put on	Discharged battery	Recharge
	Defective battery	Replace
	Defective button	Requires authorized service
	Power button not properly depressed	Press ON/OFF in three seconds
Digits flash	Low battery	Recharge the battery
Recharge indicator light can't turn on	Battery charger damaged	Check the battery charger
	The Battery charger is not plugged properly	Insert plug again
Display doesn't respond to weight changes	Faulty load cell or PCB	Requires authorized service
	Load cell cable damaged	Check and replace load cell
	Out of calibration	Check calibration
Display experiences excessive Zero drift between weighment	Scale electronics do not stabilize after turning on	After turning on, heating 3-5 minutes.
	Put the scale on ground for too long time	Scale should be hung
Displayed weight shows large error	Scale not Zeroed before applying weight	Depress ZERO before applying weight
	Requires recalibration	See calibration
	Kg/lb wrong selection	See operation
Battery can't recharge	Battery damaged	Replace battery
	Outlet damaged	Replace the outlet
Remote distance shortened	Receiver window is dirty	Check and clean
	Remote Control's battery is low	Replace Remote Control's battery.

